

INSTALLATION INSTRUCTIONS

LED WORKLIGHTS WITH TRIPOD

Product Codes: **GWLPRO-135, GWLPRO-235**

Safety Warning




- The installation should be carried out by a qualified electrician in compliance with the current edition of the IEE Wiring Regulations.
- Prior to installation, carry out the necessary risk assessment considering the people who could be at risk, the level of risk and the precautions required to control the risk.
- Ensure that the circuit supply is isolated either by the circuit supply fuse being removed or the applicable circuit breaker being turned off before installation or any maintenance.
- Check the total load on the circuit ensuring the luminaire does not exceed the rating of the circuit cable, fuse or circuit breaker.
- Long-term use and voltage fluctuations can reduce the life span of the fitting.
- If the fitting incorporates control gear, ensure careful sizing to avoid instances of nuisance tripping of the protective device used in the installation.
- Follow the provided installation instructions, using the fixings supplied or recommended.
- Keep out of reach of children.



Specification

Box Contents -
1 x Tripod, 1/ 2 x LED Head(s) & Screws

Dimensions:	GWLPRO-135: L: 200 x W: 190 x D: 30 mm GWLPRO-235: L: 200 x W: 190 x D: 30 mm
Material:	Steel Tripod, Aluminium Polycarbonate Head
Working Temperature:	Standard: -20°C to 40°C
Included:	3m Cable



Installation Instructions



1. Remove the Tripod from the box and loosen the screw at the bottom to be able to open out the three legs. Once opened out, place on a flat surface and tighten the screw back up.
2. Adjust the height of the Tripod by twisting the central pole. Once you have the height you require, twist to tighten it back up.
3. Fix the LED head(s) on the top by using the screw(s) provided, twist the LED head(s) to the position you want and fully tighten the screw(s).
4. Check that the Tripod is stable and has a solid footing. Ensure that the cable is not near any sharp objects that could cause damage to it and make sure the plug is protected against rain and moisture.
5. Connect the plug to a suitable power supply and make sure it is working correctly.
6. When the Tripod is not in use, use the hooks to safely store the cable.

Warranty

This product is covered by a 3 year warranty from the date of purchase. The warranty is invalid in the case of improper use, tampering, removal of the Q.C. date label, installation in an improper working environment or installation not according to the current edition of the I.E.E. Wiring Regulations (BS7671). The warranty is also invalidated if the luminaire has been insulation tested. Should this product fail during the warranty period it will be replaced free of charge, subject to correct installation and return of the faulty unit. We do not accept responsibility for any installation costs associated with the replacement of this product. Your statutory rights are not affected. We reserve the right to alter specifications without prior notice.

Maintenance

- This fitting will require routine cleaning if used in adverse (dust, paint, welding, oils etc) environments. Do not use solvents, aggressive detergents or abrasives.
- The light source & driver in this luminaire can not be replaced. When this fitting comes to the end of it's life or you choose to replace it, please do not dispose of it with your normal waste. Please recycle where the facilities exist, check with your local authority for suitable options.



INS/SITE/0011/GWLPRO-TRIPOD/V1



Red Arrow Electrical Ltd
Cortonwood Drive, Brompton,
Barnsley, S73 0UF

T: 0114 279 8999
sales@redarrowelectrical.co.uk

redarrowelectrical.co.uk